



DOOR AND PANEL PARTS
For Models: DU1148XTPB9, DU1148XTPQ9 (Black) (White)


UNDERCOUNTER DISHWASHER



Illus	. Part	
No.	No.	DESCRIPTION
1		Literature Parts
	8575348	,
	14/40000400	Installation
	W10066180	Energy Guide
	W10073760	,
2	W10082651	Tech Sheet
2	8534858	Arm, Hinge Left
	8534857	
3	8268983	
Ū	0200000	Door
4		Panel Front
		(Includes #7)
	W10073200	
	W10073210	
5		Access Panel
	8573255	
_	8573256	
6 7	8268580	
	8269016	
8		Toe Panel
	8573286	(Includes Clip) Black
	8573287	
9	8269740	
9 12		Screw
	302868	Black
	3400836	White
13	343641	
15	489470	Screw




CONTROL PANEL PARTS




Illus No.	. Part No.	DESCRIPTION
1		Console Asm.
		(Includes Active
		Overlay & Insert)
	W10102461	Black
	W10102462	
2	8546546	Clip, BI-Metal
4	W10056090	Cover Control
		Shield Assembly
5	8524471	Actuator, Latch
6	661663	BI-Metal
7	3400412	Screw
8	3369051	Screw (6)
9		Handle, Latch
	8534984	
	8534985	White
10	8524476	Bolt, Latch
11	8575277	
		Electronic
12	8269209	Switch, Door


DOOR AND LATCH PARTS For Models: DU1148XTPB9, DU1148XTPQ9



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus No.	. Part No.	DESCRIPTION
1	3369051	Screw, Door	7	8542566	Deflector, Vent	12	W10070130	Wiring Harness
3	8269311	Inner Door			(Also Order			Main
		(Also Order			ltem 6)	13	8281154	Screw
		Îtem 6)	8	8565814	Dispenser,	14	8269296	Seal,
5	8542603	Vent Assembly			Assembly			Console/door
		(Also Order	9	8269258	Seal, Front	15	8535637	Bracket, Dispenser
		Item 6)				16	8531865	Shield, Dispenser
6	8269259	Gasket, Vent				17	8558307	Cap, Rinse Aid


LOWER WASHARM PARTS For Models: DU1148XTPB9, DU1148XTPQ9





Illus. No.	Part No.	DESCRIPTION
1	8268333	Wash Arm Assembly
2		Cap, Internal
		Rear Feed
		(Also Order
		Ítem 3)
3	8268340	Seal, Sprayarm
4	8268342	Hub, Lower
		Sprayarm
		(Also Order
		Item 3)

HEATER PARTS
For Models: DU1148XTPB9, DU1148XTPQ9 (Black) (White)




Illus. No.	Part No.	DESCRIPTION
1	8563007	Heater Element Assembly (Also Includes Item 2)
2	717273	Washer, Heater Element
3	8268548	Nut, Heater Element
4	8269262	Bracket, Heater Support


NOTE: If heater element is removed, it must be replaced.

FILL AND OVERFILL PARTS

For Models: DU1148XTPB9, DU1148XTPQ9




TUB AND FRAME PARTS
For Models: DU1148XTPB9, DU1148XTPQ9 (Black) (White)



TUB AND FRAME PARTS For Models: DU1148XTPB9, DU1148XTPQ9

Illus. No.	Part No.	DESCRIPTION
1	W10008370	Tub Assembly
	8573061	
2 3 5	8268888	
5	8531022	Drain Loop
_		With Check Valve
8	8533836	Screw (8)
10	3367670	Screw
11	8269145	Bracket,
		Undercounter
15	8269831	Wheel Leg
16	8524584	
18	8524473	
		Balance
19	8270016	Wheel & Mount
	0.400000	Assembly
20	3400892	Screw
21	8268991	Cover, Terminal
22	0000004	Box
23	8268961 304231	,
26 27	8269016	
27 28	8573240	Clip, Grounding Shield, Sound
20	0373240	Tub
29	3378595	Bracket,
23	3370333	Thermostat
30	661566	
31	8580309	
33	8268990	Bushing, Door
00	020000	Spring
34	3378128	
35	3400014	
36	356138	
37	8269297	Miscellaneous
	-	Parts Bag
		(Includes 2 Screws
		& 2 Hose Clamps)


PUMP AND MOTOR PARTS For Models: DU1148XTPB9, DU1148XTPQ9



PUMP AND MOTOR PARTS


Illus No.	. Part No.	DESCRIPTION
1	8534952	
2	8283527 3400069	Shield, Motor Screw
4	8572618	Sump With Seal
5	8268375	Check Valve, Sump
6	8268383	
7	9741232	Screw
8 10	8531857	Protector, Inlet
11	8534942 3400217	Motor Assembly Screw
12	8268391	Screen, Separation
14	8572615	Sump & Motor
		Assembly
15	8269524	Tab, Sump
16	8533949	
17 18	661662 8531019	· · · · · · · · · · · · · · · · · · ·
10	6551019	(Also Order
		Items 23 & 30)
19	8269144	,
20	8534941	Motor
21	8268397	Seal, Volute
22	8531017	Impeller Kit
		(Also Order Item 30)
23	8268403	Face Seal Assembly
	0200 100	(Also Order
		Item 30)
24	356138	Clamp, Hose
25	W10055980	Optical Water
26	8269507	Indicator
26 27	8534946	Capacitor Shield,
۲,	000-0-0	Capacitor
30	8531018	Washer

UPPER RACK AND TRACK PARTS




Illus. No.	Part No.	DESCRIPTION
1	8539214	Dishrack, Upper
2	8268655	Mount, Wheel
3	3385089	Track, Rack
4	8565920	Stop Track


UPPER WASH AND RINSE PARTS For Models: DU1148XTPB9, DU1148XTPQ9



Illus. No.	Part No.	DESCRIPTION
1	8558968	Feed Tube Assembly (Also Includes Items 3 & 9)
2	8533889	,
3	8557720	Spinner, 3rd Level Wash
4	3400919	
5	8268321	,
6	8268326	Manifold
7	8268325	Holder, Feed Tube
8	8268433	Seal, Sprayarm
9	8268293	Nozzle
10	8269024	Sprayarm
11	3400850	Screw

LOWER RACK PARTS





Illus. No.	Part No.	DESCRIPTION
1	8539226	Lower Rack Assembly
2	8535075	Silverware Basket
3	8268645	Wheel & Transport Assembly
4	8268869	Tinerow, Folding
6	8539124	Retainer, Tinerow
7	8539118	Latch Assembly
8	8535077	Door, Silverware Basket
9	8535078	Lid, Silverware Basket
10	8269308	Clip, Silverware Basket

OPTIONAL PARTS (NOT INCLUDED) For Models: DU1148XTPB9, DU1148XTPQ9

(Black) (White)

Illus. **Part**

DESCRIPTION No. No.

ACCESSORIES

Side Panel Kits 8171656 White 8171657 Black 8171658 Biscuit 8171659 Stainless Steel

Custom Panel & Trim Kit 4396199 Black 4396200 White 4396201 Biscuit

Moisture Barrier Kit 4396277 Kit

Drain Hose 3385556 12 Ft. Illus. **Part**

DESCRIPTION No. No.

PAINT, TOUCH-UP (1/2oz.)

72017 White 72032 Black 4392899 Biscuit 4396603 Meteorite

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White 285006 Superior Black 4392901 Biscuit

PAINT, BULK (1 qt.)

799344 White (Uncut) 4392900 Biscuit

Illus. Part

DESCRIPTION No. No.

POWER CORD KIT

4317824 Power Cord Kit (Includes Power Cord & Misc. Hardware)

ANTI-TIP KIT

4396194 Floor Mount Kit

DISHRACK REPAIR

Tip Tine Repair Kit (Enough for Two Complete Dishracks)

> 4396838 White 4396840 Grey

Vinyl Touch-Up (4 oz.) 676453 White 676455 Grev